

Before Starting Work.

АЗНА ХНОМ

- petrol, or gas cylinders. a danger of explosion. It will ignite tumes from Do not use this pressure washer where there is 1
- Do not use this pressure washer in the rain or
- лам таб либни залад волгова ант азайм
- that no-one is near to you or could distract you. Make sure that the area is clear and safe and
- sure you have good drainage for the waste spray. Use a wash bay, or erect barriers. Make Protect other people from the noise and water °t
- supply socket. οι water being sprayed onto the electricity Set up the work area so that there is no danger ·g

СИСТАНАНО

- require a higher level of protection. washer. Particular jobs or environments may be worn whenever you use this pressure equipment (ppe) are the minimum that should The following items of personal protective 1
- миеи москид мии иля шаспие. Impact resistant visor or goggles must be worn **'**Z
- Anybody who is working near to you will also °t are waterproot. You should wear overalls, boots, and gloves that 3
- nueudinba need to wear appropriate personal protective

Speedy

- pressure water noses and all equipment. It Check the pressure washer, cables, plugs, high 1 RESSURE WASHER
- pressure washer contact the hire company. anything is found damaged, do not use the
- Check that the plug on your equipment matches **'**Z
- improvise tnem. your supply. Do not try to force connections or

The Crescent Birmingham Business Park มกอา รมมอติอม กระว Association Europe

3YT TEB Iludilos

eading. HAE/EHA cannot accept responsibility for any loss or liability perc of any such document/material. Only Acts of Parliament and Statutory Ins

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting materia

oron the use of any such document/material. Only Acts of Parliament and Statu have the force of law and only the courts can authoritatively interpret the law.

:lism3 :euoudeie

0812 Safety Guidance

It is important to read all of this leaflet

BEFORE you use the Pressure Washer

1. Plan the use of the pressure washer so it can always be used

Electricity is dangerous and must always be used with great care.

Water and electricity make a dangerous combination. Keep water

This pressure washer is designed for high pressure water washing.

Plan and think ahead to make sure you will always be working safely.

Impact resistant visor or goggles; Waterproof overalls; Waterproof boots; Gloves;

The following personal protective equipment should always be worn

Pressure Washer

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

The action of this pressure washer can cause injury or damage if the equipment is not used in a

If you have not used a pressure washer before, take time to familiarise yourself with how the

- doubt about how clean your water supply is.

WATER SUPPLY

.9iaissoq

1

2

·9

.C

.4

.5

- You must use a suitable filter if you are in any

watel is ciean



- 3. If using chemicals or detergents, follow the

If your supply is from a water tank make sure the

Before you switch on the washer, you must know how to control it and switch it off safely.

Make sure you understand all of the controls

Make sure that none of the hose connections get

Make sure that all the pressure hose

away from the electricity supply, without having to use long extension cables. Always use

Extension hoses may have been supplied by the hire company. These allow you to work further

Ensure it is laid out safely with no kinks, away

Use only the hose supplied with the machine.

have either a normal square pin plug fitted, or a

designed to run directly from 230v mains will

it may be heavier than you think. Equipment

care not to injure yourself when moving it about

a portable transformer nas been supplied, take

equipment from a normal mains 230V supply. If

portable transformer if you need to power the

supply. The hire company will have provided a

NULT listoga a to run of bangised si betti purg

εαμιρωέα κιτά ε σγιπατίζει γείταν παυσττιδι

from where vehicles may run over it.

. Oute industrial plug.

ision hoses instead of extension cables it

dirty when you are setting-up the machine.

connections are firm and tight.



is accurate and not misl





to have arisen t

safely.

away from electrical parts.

careful and controlled way.

equipment works before starting to use it.

2


3

4.

5

7.

8







For guidance on managing

construction health risks go to

www.hse.gov.uk/construction

Using the Pressure Washer

Hold the lance in both hands when squeezing the trigger because the water pressure will make it

Do not aim the water jet at yourself, any other persons, or any animals. It will cause an injury. Do not spray the water jet over any electrical equipment. This could cause a short circuit and

If the cable is cut or damaged in any way, dry your hands switch off and unplug at the mains

before inspecting it. If the cable attached to the pressure washer is damaged, stop using the

equipment. Contact the hire company. If an extension cable has been damaged do not use it

If you suspect there is a fault in the electricity supply to the socket, do not attempt to repair it.

Do not connect or disconnect a pressure hose or lance while the washer is pressurised. Turn

Switch off the washer at the mains and squeeze the lance trigger to release the pressure when

11. If working in cold conditions, make sure that the water in the machine will not start to freeze

12. After work turn the detergent off or remove the detergent feed. Run the washer on just water to

flush the detergent out. Then turn off the water pump motor, and squeeze the lance trigger to

Switch off and remove the plug from the socket before leaving the machine unattended.

off the water pump motor, and squeeze the lance trigger to release the pressure.

release the pressure. Dry hands, switch off at the mains and unplug the washer.

Wear protective equipment including goggles and waterproof overalls

fire. This could cause a fatal electric shock.

Take care not to accidentally pull the plug from the socket.

13. Drain the machine if there is any danger of overnight frost.

Contact a competent electrician



m Busin

Hire Association Europe 2450 Regents Court The Crescent olibull B37 7YE

1.

2.

3.

4

5.

6.

7.

8.

g.

10

15.

"kick back"

again

not in use

machine

when not in use.

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

are dry and sare

Make sure that any extension cable connections

.910 Unroll it fully or it will overheat and could catch

doorways or windows where it might be trapped, and places where vehicles might run over it.

special

against electric shock if the cable or equipment

A. Make sure that any extension cable connections

vehicles might run over it. Unroll it fully or it will

liquids, sharp edges, doorways or windows where it might be trapped, and places where

Lay the extension cable out carefully avoiding

proof socket, not longer than 50 metres (160 teet). You must only use an extension cable


instructions, you should only use a suitably rated heavy duty 110v extension cable with a splash

between the transformer and the equipment.

noΪ







.begemab ets

1

3

will help to protect

equipment into the rcd. This

the 230volt socket. Plug the

("rcd") plugged directly in to

Use a residual current device

OVERTERI AND COULD CALCH TIFE.

(צמחאת אוא סא אנטב אנטפ)

230 VOLT EQUIPMENT

are dry and sale.



not use any 230v extension cables. If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do

It you nave to use an extension capie, it must e

working at a distance from the electricity supply.

Using extension hoses is a much safer way of

Do not use an extension cable unless it is

Make sure the pressure washer is switched off

Do not touch any switches, plugs, or sockets

before you plug it in to the supply.

uniess your nangs are dry.

плертал и пределати постат

·7

plug fitted, or a blue industrial plug.

necessary to do so.

ELECTRICAL SAFETY

industrial plug fitted.

1

.C

.4

3

.1

e.org.uk

- If you need to use an extension cable, follow any special

have not given any special instructions given by the hire company. If the hire company

