
EN 2000W BLACK PTC DIGITAL PROMO




EN **IMPORTANT -** These instructions are for your safety. Please read through them thoroughly prior to handling the product and retain them for future reference.
This product is only suitable for well insulated spaces or occasional use.

V30426_5063022913395_MAND4_2425_TF001822

5063022913395

EN Parts



01. x1

EN You will need




EN Contents

EN	
Product description	3
Safety	4
Guarantee	13
Use	14
Care & Maintenance	18

5063022913395_MNL_EN_V03.indd 2 2026/4/28 17:55

EN



1	White LED display with icons
2	Control panel with touch keys
3	Front grille
4	Hot or vented air outlet
5	Integrated handle
6	Air inlet
7	Electric power cord entry
8	Foot
9	Tip over safety

5063022913395_MNL_EN_V03.indd 3 2026/4/28 17:55

EN
Before you start

- Read these important instructions carefully before using the appliance.
- Keep these instructions during all the appliance's lifespan for future reference.
- Always give these instructions to anyone who will use the appliance, even if it's transferred to a third party.
- Failure to observe safety instructions can cause potential injuries or property damage (Electric shock, burns, fire, …)
- Instructions are intended to protect your health and health of others, but also prevent potential damage to the appliance.
- This appliance is only intended to heat a living space in a domestic application and under no circumstances in a commercial or industrial professional setting.

WARNING : THIS PRODUCT IS ONLY SUITABLE FOR WELL INSULATED SPACES OR OCCASIONAL USE.
IT SHALL BE USED AS AN AUXILIARY MEANS OF HEATING, IN COMPLEMENT, NOT AS A PRIMARY MEANS OF HEATING.

- This appliance is in conformance with European Union, United Kingdom and Ireland regulations.
- Please contact a qualified electrician or a professional installer if you need assistance for the appliance installation including aspects regarding electric part.

Safety

- Before use, always refer to the instructions and precautions intended to the assembly, installation, cleaning and maintenance as well as symbols explanations.

5063022913395_MNL_EN_V03.indd 4 2026/4/28 17:55

- Remove all packaging parts before installation and use.



WARNING : KEEP PACKAGING MATERIALS AND ACCESSORIES OUT OF THE REACH OF CHILDREN. NEVER ALLOW CHILDREN TO PLAY WITH PACKAGING OR ACCESSORIES. POTENTIAL BAGS IN PLASTIC OR EQUIVALENT MATERIAL INCLUDED WITH PACKAGING ELEMENTS SHALL BE KEPT AWAY FROM CHILDREN.



DANGER : RISK OF SUFFOCATION. BAGS ARE NOT TOYS.

- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure that they do not play with the appliance.

5063022913395_MNL_EN_V03.indd 5 2026/4/28 17:55

- Cleaning and user maintenance shall not be made by children without supervision.

CAUTION : SOME PARTS OF THIS PRODUCT CAN BECOME VERY HOT AND CAUSE BURNS. PARTICULAR ATTENTION HAS TO BE GIVEN WHERE CHILDREN AND VULNERABLE PEOPLE ARE PRESENT.

- This appliance can be used at a maximum altitude of 2000 m.
- The heater must not be located immediately below a socket outlet.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Do not use this heater if it has been dropped.
- Use this heater on a horizontal and stable surface.

WARNING : DO NOT USE THIS HEATER IN SMALL ROOMS WHEN THEY ARE OCCUPIED BY PERSONS NOT CAPABLE OF LEAVING THE ROOM ON THEIR OWN, UNLESS CONSTANT SUPERVISION IS PROVIDED.

WARNING : TO REDUCE THE RISK OF FIRE, KEEP TEXTILES, CURTAINS, OR ANY OTHER FLAMMABLE MATERIAL A MINIMUM DISTANCE OF 1 M FROM THE AIR OUTLET.

WARNING : RISK OF DAMAGE. DO NOT LEAN AGAINST THE APPLIANCE OR SIT ON IT.

5063022913395_MNL_EN_V03.indd 6 2026/4/28 17:55

DANGER : NEVER PLACE LIQUIDS OR SOLIDS OBJECTS ON THE APPLIANCE WHEN IN USE OR STORED.

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

CAUTION : IN ORDER TO AVOID A HAZARD DUE TO INADVERTENT RESETTING OF THE THERMAL CUT-OUT, THIS APPLIANCE MUST NOT BE SUPPLIED THROUGH AN EXTERNAL SWITCHING DEVICE, SUCH AS A TIMER, OR CONNECTED TO A CIRCUIT THAT IS REGULARLY SWITCHED ON AND OFF BY THE UTILITY.

Installation

- This appliance is designed to be freestanding.
- Minimum spaces between the appliance and surrounding structures shall be observed, please refer to the installation schemes.

WARNING : ALWAYS CHECK THE SURROUNDING STRUCTURES THERMAL RESISTANCE BEFORE INSTALLATION BECAUSE SOME MATERIALS ARE SENSITIVE TO HEAT. AVOID DIRECT EXPOSITION OF THE APPLIANCE AND ITS POTENTIAL ACCESSORIES TO SUNLIGHT.

DANGER : NEVER INSTALL OR USE THIS APPLIANCE OUTSIDE, INDOOR USE ONLY.

5063022913395_MNL_EN_V03.indd 7 2026/4/28 17:55

- Do not install the appliance on carpet, rugs or a similar covering.

Electric connection

- The electrical plug must remain accessible or a means for disconnection having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules, in order to allow the appliance disconnection from the electric supply in all circumstances.



DANGER : BEFORE ACCESSING THE CONNECTION TERMINALS, ALL ELECTRIC SUPPLY CIRCUITS MUST BE DISCONNECTED.

- The appliance electrical protection is ensured by a double insulation which does not require a connection to earth.
- The appliance power supply current is alternating type.
- Unwind the supply cord completely and check there is no damage on it.



DANGER : NEVER CONNECT / DISCONNECT THE APPLIANCE ELECTRIC SUPPLY WITH WET HANDS, RISK OF ELECTRIC SHOCK.



CAUTION : DO NOT BEND, CRUSH OR PINCH THE ELECTRIC SUPPLY CORD BEHIND THE APPLIANCE. LEAVE ENOUGH SPACE BEHIND THE APPLIANCE SO THAT IT IS NOT IN DIRECT CONTACT WITH THE FIXED ELECTRIC WIRING SYSTEM.

5063022913395_MNL_EN_V03.indd 8 2026/4/28 17:55

WARNING : ALWAYS ENSURE YOUR FIXED ELECTRIC WIRING SYSTEM CAN MANAGE THE APPLIANCE'S RATED POWER.
IF THE POWER CORD BECOMES VERY HOT, IT MEANS YOUR ELECTRIC INSTALLATION IS NOT ABLE TO MANAGE THE APPLIANCE RATED POWER.

WARNING : FOR AN INSTALLATION INSIDE A WATER ROOM SUCH AS A BATHROOM OR A SHOWER ROOM, THE APPLIANCE MUST COMPLY TO STRICT INSTALLATION LOCATIONS DEPENDING ON THE ROOM PROTECTION VOLUMES, THE APPLIANCE'S ELECTRIC PROTECTION CLASS, ITS LIQUID INGRESS PROTECTION CODE AND THE NATIONAL ELECTRICAL INSTALLATION RULES.

5063022913395_MNL_EN_V03.indd 9 2026/4/28 17:55


Only for United Kingdom and Ireland:

WARNING : RISK OF ELECTRIC SHOCK AND FIRE! THE FOLLOWING OPERATIONS SHALL BE PROCEEDED BY A QUALIFIED ELECTRICIAN IF YOU ARE UNFAMILIAR WITH NATIONAL ELECTRIC RULES OR HAVE NO SUFFICIENT TECHNICAL KNOWLEDGE.


Plug Replacement

- This appliance is fitted with a BS 1363 non-moulded electric plug including a 13 A(Ampere) fuse adapted to the appliance rating power.
- Should the fuse require replacement, please carefully open the fuse holder with the help of a hand screwdriver.
- The fuse must be replaced by an approved BS 1362 fuse with exactly the same amperage intensity in A than the original fuse included. Please note the electric fuse has no polarity.


1



2



3



5063022913395_MNL_EN_V03.indd 10 2026/4/28 17:55

WARNING : SHOULD THE MOULDED ELECTRIC PLUG IS DAMAGED, IT MUST BE REPLACED WITH THE SUPPLY CORD TOGETHER BY THE MANUFACTURER, ITS SERVICE AGENT OR SIMILARLY QUALIFIED PERSONS IN ORDER TO AVOID A HAZARD.

CAUTION : FOR UNITED KINGDOM AND IRELAND, THE INSTALLATION IN A WET ROOM SUCH AS A BATHROOM OR A SHOWER ROOM IS FORBIDDEN.

WARNING : FOR FRANCE, POLAND, ROMANIA, SPAIN, PORTUGAL, AND TÜRKIYE, INSTALLATION INSIDE A WET ROOM SUCH AS A BATHROOM OR A SHOWER ROOM MUST COMPLY TO STRICT INSTALLATION LOCATIONS DEPENDING ON:

- THE ROOM'S PROTECTION VOLUMES
- THE LOCATION OF THE MAINS ELECTRICAL OUTLET
- THE APPLIANCE'S ELECTRICAL PROTECTION CLASS
- THE APPLIANCE'S LIQUID INGRESS PROTECTION CODE
- THE NATIONAL ELECTRICAL INSTALLATION RULES

5063022913395_MNL_EN_V03.indd 11 2026/4/28 17:55

- Please contact a qualified electrician if you are unfamiliar with national electric rules or if you have no sufficient technical knowledge.



CAUTION : WHERE AN ELECTRIC HEATER, INCLUDING ITS ELECTRICAL CONNECTION TO THE MAINS, EXTENDS IN SEVERAL PROTECTION VOLUMES, THE TECHNICAL SPECIFICATIONS APPLY TO THE CLOSEST VOLUME OF THE WATER ZONE.



DANGER : NEVER USE THIS HEATER NEAR A SINK, A BASIN, A BATHTUB, A SHOWER, OR A SWIMMING POOL. RISK OF ELECTROCUTION DUE TO AIR AMBIENT MOISTURE AND POTENTIAL SPLASHING.



WARNING : IN ORDER TO AVOID OVERHEATING, DO NOT COVER THE HEATER.

- Do not use if there are visible signs of damage to the heater.

5063022913395_MNL_EN_V03.indd 12 2026/4/28 17:55

Technical Data

Model	NT20-20AR
Rated electric supply	220-240 V ~ 50 Hz
Rated power (Full power II)	2000 W
Fan power	12,5 W
Half power I	1200 W
Electric protection class	Class II
Ambient temperature operating range	5°C to + 35°C
Dimensions	Height : 22,0 cm / Width : 16,4 cm / Depth : 12,3 cm
Weight	1.32 Kg

	This product complies with conformity requirements of the applicable European Regulations or Directives.
	This product complies with conformity requirements of the applicable UK Regulations.
	The appliance electrical protection is ensured by a double insulation which does not require a connection to earth.
	Read the instructions.
	This symbol is known as the ‘Crossed-out Wheelie Bin Symbol’. When this symbol is marked on a product or battery, it means that it should not be disposed of with your general household waste. Some chemicals contained within electrical / electronic products or batteries can be harmful to health and the environment. Only dispose of electrical/electronic/ battery items in separate collection schemes, which cater for the recovery and recycling of materials contained within. Your co-operation is vital to ensure the success of these schemes and for the protection of the environment.
	The appliance power supply current is alternating type.
	**WARNING:** In order to avoid overheating, do not cover the heater.

5063022913395_MNL_EN_V03.indd 13 2026/4/28 17:55

Recycling and disposal

When scrapping the heater, follow the regulations concerning the disposal of oil.

At the end of its life, the product must not be sorted or recycled with other domestic waste.

You are legally responsible for sorting the appliance and its potential accessories, as well as packaging elements and the instructions manual.

Separate collection schemes are scheduled for the collection and recycling to avoid the dispersion of harmful substances for the health and the environment.

Please always observe national and local regulations to reduce the environmental impact of your purchase.

Guarantee

We take special care to select high quality materials and use manufacturing techniques that allow us to create products incorporating design and durability. This product has a manufacturer's guarantee of 2 years against manufacturing defects, from the date of purchase (if bought in store) or date of delivery (if bought online), at no additional cost for normal (non-professional or commercial) household use.

To make a claim under this guarantee, you must present your proof of purchase (such as a sales receipt, purchase invoice or other evidence admissible under applicable law), please keep your proof of purchase in a safe place. For this guarantee to apply, the product you purchased must be new, it will not apply to second hand or display products. Unless stated otherwise by applicable law, any replacement product issued under this guarantee will only be guaranteed until expiry of the original period guarantee period.

This guarantee covers product failures and malfunctions provided the product was used for the purpose for which it is intended and subject to installation, cleaning, care and maintenance in accordance with the information contained in these terms and conditions, in the user manual and standard practice, provided that standard practice does not conflict with the user manual.

This guarantee does not cover defects and damage caused by normal wear and tear or damage that could be the result of improper use, faulty installation or assembly, neglect, accident, misuse, or modification of the product. Unless stated otherwise by applicable law, this guarantee will not cover, in any case, ancillary costs (shipping, movement, costs of uninstalling and reinstalling, labour etc), or direct and indirect damage.

If the product is defective, we will, within a reasonable time, provide spare parts.

Rights under this guarantee are enforceable in the country in which you purchased this product. Guarantee related queries should be addressed to the store you purchased this product from.

The guarantee is in addition to and does not affect your statutory rights.

IMPORTANT - RETAIN THIS INFORMATION FOR FUTURE REFERENCE: READ CAREFULLY


5063022913395_MNL_EN_V03.indd 14 2026/4/28 17:55

EN



Key	Action	Description
	On / Stand-by	Short press the key to turn on or stand-by the appliance : - The power in icon is visible in permanence as long as the appliance is in stand-by mode - At stand-by, a 30 s countdown is displayed when the heating element is hot, this is a safety fan cooling duration prior to stand-by - An auto off function is integrated for safety with automatic stand-by after 24 h if no action is made on the control panel keys
	Modes setting	In on mode, short press the key to scroll the different modes between : - P0 : Fan mode without heating and without room temperature thermostat P0 is displayed on the digits - P1 : Fan + heating at low power with room temperature thermostat The icon P1 is displayed - P2 : Fan + heating at full power with room temperature thermostat The icon P2 is displayed

5063022913395_MNL_EN_V03.indd 15 2026/4/28 17:55

	Timer setting	In on mode, short press or press and hold the key to scroll the timer duration : - The icon ◷ is displayed - The defaut setting is off and the default duration is 1 h - The duration can be set from 1 h to 24 h - The remaining duration is displayed in flashing alternance with the mode P0 or the room temperature thermostat in P1 & P2 modes - Scroll the timer duration to 0 h or press and hold the keys ◷ + ≋ few seconds to cancel the timer duration
	Thermostat temperature setting	In on mode, out in the P0 mode (Fan only), short press or press and hold the key to scroll the room thermostat temperature setting : - The default temperature is 20°C - The temperature can be set from 05 to 35°C according to your needs - When the room temperature is reached, a 30 s safety fan cooling duration is automatically made prior to stop
	Silent mode	In on mode, press and hold the keys few seconds to activate or deactivate the silent mode that will remove the buzzer. The default setting is off.

When using the appliance for the first time or after a long period of inactivity, an unpleasant odour may be felt. This is normal and will fade after a few minutes.

Please note a memory is included to save your personal settings as long as the appliance remains powered.

Information requirements for electric local space heaters

Contact details	Kingfisher International Products Limited, 1 Paddington Square, London, W2 1GG, United Kingdom www.kingfisher.com/products		
Model identifier(s)	NT20-AR		
Item	*Symbol*	*Value*	*Unit*
Heat output			
Nominal heat output	P_{nom}	2.000	kW
Minimum heat output (indicative)	P_{min}	1.400	kW
Maximum continuous heat output	$P_{max,c}$	2.000	kW
Power consumption			
In off mode	P_{o}	0.00	W
In standby mode	P_{sm}	0.28	W
In idle mode	P_{idle}	0.32	W
In network standby	P_{nsm}	0.00	W
Standby mode with display of information or status	■		
Seasonal space heating energy efficiency in active mode	$N_{S,on}$	92.0	%
Type of heat output/room temperature control			
Single stage heat output and no room temperature control	□		
Two or more manual stages, no room temperature control	□		

5063022913395_MNL_EN_V03.indd 16 2026/4/28 17:55

With mechanic thermostat room temperature control	□
With electronic room temperature control	□
Electronic room temperature control plus day timer	■
Electronic room temperature control plus week timer	□
Other control options	
Room temperature control, with presence detection	□
Room temperature control, with open window detection	□
Distance control option	□
Adaptive start control	□
Working time limitation	■
Black bulb sensor	□
Self-learning functionality	□
Control accuracy	□
	■ : Yes /□: No

Troubleshooting

Operation of your appliance can lead to errors and malfunctions. The following tables contain possible causes and tips to resolve them. Please consult this table before to contact after sales service.

Troubles	Possible causes	Solutions
The appliance is not powered on.	The appliance is not plug in correctly to the electric mains.	Check the power cord is not trapped, bended, crushed, pinched or damaged.
		Plug in the appliance into an electric socket outlet.
		Check the power plug is firmly inserted.
	Overheat protection has been triggered.	An overheat safety is included inside the appliance. Ensure there is no objects or textiles on or near the appliance, then unplug the appliance and let it cool down at least half of an hour before to replug in.
The appliance is powered on but does not heat up.	The temperature thermostat knob is set below to the room ambient temperature.	Adjust the temperature thermostat knob above the room ambient temperature, a “click” sound will be heard when the thermostat will trigger.
The appliance suddenly stops during heating.	The appliance stops heating after reaching the heating temperature set.	No abnormal situation. If the heating stops too frequently according to your heating needs, set the temperature thermostat knob higher.
	The appliance is or was tipped over.	A tip over switch safety is included inside the appliance. Ensure the appliance is on a flat and stable surface, then unplug and replug in the appliance.

If you encounter a problem using your appliance, make sure to follow the instruction manual including chapters relating to cleaning, servicing and maintenance.

Check the possible error codes descriptions according to the appliance.

5063022913395_MNL_EN_V03.indd 17 2026/4/28 17:55

If the problem is not resolved despite these steps, we invite you to contact the after-sales service of the place of your purchase through the retail banner store or its website.

CAUTION : ANY PRODUCT INTERVENTION AND / OR REPAIR BY THE USER OR A NON-PROFESSIONAL THIRD PARTY MAY JEOPARDIZE THE SAFETY OF PERSONS AND PROPERTY.
SO, DO NOT ATTEMPT TO DISASSEMBLE THIS APPLIANCE, REPAIR IT OR PERFORM ANY MODIFICATIONS BY YOURSELF.

WARNING : DEFECTS AND THEIR CONSEQUENCES RESULTING FROM PRODUCT INTERVENTIONS AND / OR REPAIRS CARRIED OUT BY THE USER, OR A NON-PROFESSIONAL THIRD PARTY CANNOT GIVE RISE TO THE APPLICATION OF THE LEGAL OR COMMERCIAL WARRANTY.

CAUTION : THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR DAMAGE OCCURRING DURING SELF-REPAIR INSOFAR AS THIS DAMAGE IS LINKED IN PARTICULAR TO USER ERROR OR NON-COMPLIANCE BY THE LATTER WITH THE PRODUCT REPAIR INSTRUCTIONS.

DANGER : BEFORE ANY INTERVENTION, ALL ELECTRIC SUPPLY CIRCUITS MUST BE DISCONNECTED.

ANTI-TILT SWITCH PROTECTOR

This appliance is equipped with a safety tip-over switch which automatically shuts off the appliance if the appliance is not in the upright position.

The appliance will resume back to stand-by when returned to the upright position.

AUTO SATETY SHUT OFF

The appliance has a built-in safety device which will switch the appliance off in case of accidental overheating.

To reset the appliance, stand-by the appliance and unplug it.

The appliance will resume back to normal after 30 minutes cooling down.

If the appliance does not operate again, it means the thermal safety fuse is broken and has to be replaced.

5063022913395_MNL_EN_V03.indd 18 2026/4/28 17:55

EN



WARNING : ANY INTERVENTION RELATING TO THE APPLIANCE CLEANING, SERVICING OR MAINTENANCE MUST BE CARRIED OUT AFTER COMPLETE COOLING AND ALL ELECTRIC SUPPLY CIRCUITS DISCONNECTED.



DANGER : NEVER IMMERSE THE APPLIANCE IN WATER OR OTHER LIQUIDS AND NEVER HOLD IT UNDER RUNNING WATER.



WARNING : NEVER APPLY DETERGENT, CHEMICAL AGENTS OR SOLVENTS AS THEY COULD DAMAGE THE APPLIANCE, THE MATERIALS AND THE COATINGS, ESPECIALLY PLASTIC PARTS. LIKEWISE, ABRASIVE BRUSHES OR SHARP OBJECTS SHOULD NOT BE USED AS THIS COULD SCRATCH OR DAMAGE THE APPLIANCE.

- Do not use a steam cleaner when cleaning the appliance.
- Clean the appliance regularly, once a month maximum.
- The casing can be clean by wiping gently a soft non-abrasive dust cloth, a microfiber type can be used.If stains are visible, the cloth can be slightly dampened with water and a little mild soap can be added.
- Without dismantling the air outlet guards, we recommend you to use a vacuum cleaner with its nozzle placed on guards grids to remove dust or dirt that may have accumulated inside the appliance.



DANGER : DO NOT INSERT ANY OBJECT OR TOOLS INSIDE THE APPLIANCE.

Availability of spare parts

Spare parts are available to professional repairers for a minimum period of **10 years** after purchasing the product new.

The **remote control** (If originally included with your appliance) is available for at least the same period to both professional repairers and end users.

Repairs to this product must be carried out by professional repairers only.

Any unauthorised attempt of repairing will invalidate the warranty.

Please visit www.kingfisher.com/products for more information.

5063022913395_MNL_EN_V03.indd 19 2026/4/28 17:55

Manufacturer:

UK Manufacturer:
Kingfisher International Products Limited,
1 Paddington Square, London, W2 1GG,
United Kingdom

EU Manufacturer:
Kingfisher International Products B.V.,
Rapenburgerstraat 175E,
1011 VM Amsterdam,
The Netherlands

EN www.diy.com
www.screwfix.com
www.screwfix.ie
To view instruction manuals online,
visit www.kingfisher.com/products
Made in China